

































- Parts list -

Mode	MD mode	Mod. des. overview	PASSSENGER CAR,COUPE
FIN/MD	123043	Catalog	303
VIN		Major assembly:	M - Engine
Sales designation	230 C	Major assembly MD	115954
Assortment class	Car	Group	07 - CARBURETOR
Market	All	Subgroup	001 - INJECTION PUMP

Item no.	Part number	Designation/description	Quantity	Version
----	A 001 070 16 04	CARBURETOR Replaced by: A 001 070 47 04 +001 A 000 158 14 35 +001 A 123 805 00 22 +001 A 008 997 47 82  [024] Up to engine:	-	M
----	A 001 070 41 04	CARBURETOR Replaced by: A 001 070 47 04  [029, 051] As of engine	-	M
8	A 001 070 47 04	CARBURETOR	001	M
----	A 001 070 18 04	CARBURETOR Replaced by: A 001 070 48 04 +001 A 000 158 14 35 +001 A 123 805 00 22 +001 A 008 997 47 82  [024] Up to engine:	-	A
----	A 001 070 42 04	CARBURETOR Replaced by: A 001 070 48 04  [029, 051] As of engine	-	A
8	A 001 070 48 04	CARBURETOR	001	A
11	A 000 070 24 46	. VALVE  [062] Up to engine:	001	
15	A 000 071 05 65	. SCREW BY-PASS AIR ADJUSTMENT	001	
18	A 000 071 21 72	. NUT BY-PASS AIR ADJUSTMENT	001	
21	A 000 071 00 67	. CONNECTOR  [062] Up to engine:	001	
22	A 000 071 52 80	. GASKET  [002] NO LONGER AVAILABLE INDIVIDUALLY, BUT ONLY IN GASKET KIT	-	
24	A 000 071 90 71	. SCREW  [062] Up to engine:	002	
28	A 000 071 08 70	. STUD THROTTLE VALVE LEVER	001	
		SEE FIG. NO.: 065 SEE FIG. NO.: 066		
38	A 000 070 25 53	. VACUUM BOX Replaced by: A 000 070 09 53  [415] THIS NOTE OF REPLACEMENT APPLIES ONLY TO THE ITEM LIST...	-	A
38	A 000 070 09 53	.. VACUUM BOX Replaced by: A 000 070 29 53	-	A
38	A 000 070 29 53	.. VACUUM BOX	001	A
42	A 000 071 04 95	.. BRACKET TO 000 070 25 53	001	A
----	A 000 071 14 95	.. BRACKET TO 000 070 29 53	001	
46	N 006797 012250	. TOOTHED WASHER	001	A
50	N 000936 012005	.. NUT	001	A
53	A 000 071 31 16	.. SPRING Replaced by: A 000 071 74 16	-	A
53	A 000 071 74 16	.. SPRING	001	A
57	A 000 071 18 72	.. NUT Replaced by: A 000 071 22 72	-	A
57	A 000 071 22 72	.. NUT	001	A
57	N 000439 005201	.. NUT	001	A
60	N 000933 005075	.. SCREW Replaced by: N 304017 005002	-	A
60	N 304017 005002	.. SCREW	001	A

----	A 008 997 47 82	. . HOSE Replaced by: A 117 997 09 82	-	A
62	A 117 997 09 82	. . HOSE FROM VACUUM BOX TO CARBURETOR  [404] ORDER BY THE METER	001	A
63	A 000 071 00 62	. THRUST WASHER	001	M
64	A 000 070 27 21	. LEVER	001	A
65	A 000 994 13 10	. LOCK STOP LEVER TO THROTTLE VALVE SHAFT	001	
----	A 000 071 04 72	. NUT Replaced by: N 000936 008004	-	
66	N 000936 008012	. NUT STOP LEVER TO THROTTLE VALVE SHAFT	001	
67	N 000933 005059	. SCREW	002	A
70	N 912004 005100	. LOCK WASHER	002	A
----	A 000 070 17 47	. CHOKE HOUSING Replaced by: A 000 070 21 47 +001 A 000 158 14 35 +001 A 123 805 00 22 +001 A 008 997 47 82  [415, 024] THIS NOTE OF REPLACEMENT APPLIES ONLY TO THE ITEM...	-	
73	A 000 070 21 47	. CHOKE HOUSING  [029, 062] As of engine	001	
77	A 000 070 47 52	. . DIAPHRAGM Replaced by: A 000 070 50 52	-	
77	A 000 070 50 52	. . DIAPHRAGM TO 000 070 10 47,000 070 13 47 TO 000 070 17 47,000 070 21 47 TO 000 070 31 47	001	
80	A 000 071 63 80	. . GASKET	001	
83	A 000 071 58 16	. . SPRING Replaced by: A 000 071 65 16	-	
83	A 000 071 65 16	. . SPRING	001	
----	A 115 071 00 67	. . CONNECTOR Replaced by: A 000 071 14 29	-	
84	A 000 071 14 29	. . COVER  [062] Up to engine:	001	
86	A 000 071 13 62	. . THRUST WASHER	001	
88	A 001 071 39 71	. . SCREW  [062] Up to engine:	001	
----	A 000 071 29 22	. . LEVER Replaced by: A 000 071 30 22	-	
89	A 000 071 30 22	. . LEVER	001	
90	A 012 997 62 82	. . . HOSE FOLLOWER LEVER	001	
92	A 000 071 91 71	. SCREW	002	
93	A 001 071 25 71	. SCREW	001	
94	A 000 071 51 80	. GASKET	001	
----	A 000 071 26 28	. AUTOMATIC CHOKE COVER Replaced by: A 000 071 33 28	-	
----	A 000 071 30 28	. AUTOMATIC CHOKE HOUSING Replaced by: A 000 071 33 28  [051] EXHAUST STOCK OF OLD PARTS UP TO ENGINE	-	
97	A 000 071 33 28	. AUTOMATIC CHOKE COVER CHOKE COVER	001	
100	A 000 071 23 60	. SEAL RING	001	
103	A 001 071 20 71	. SCREW	003	
107	A 000 071 48 80	. GASKET Replaced by: A 000 071 83 80	-	
107	A 000 071 83 80	. GASKET	001	
109	A 001 071 05 71	. SCREW  [062] Up to engine:	001	
115	A 000 071 02 67	. CONNECTOR  [062] Up to engine:	001	
118	N 000933 008147	. SCREW Replaced by: N 304017 008021	-	
118	N 304017 008021	. SCREW	001	
122	N 007603 008106	. SEAL RING	001	
126	A 000 071 30 24	. LINK  [062] Up to engine:	001	
130	A 000 071 18 15	. SPRING Replaced by: A 000 071 22 15	-	
130	A 000 071 22 15	. SPRING Replaced by: A 000 071 24 15	-	
130	A 000 071 24 15	. SPRING Replaced by: A 000 071 26 15	-	

130	A 000 071 26 15	. SPRING	001
134	A 000 071 09 14	. LEVER  [062] Up to engine:	001
138	A 000 071 01 26	. DIAPHRAGM	001
142	A 000 071 34 16	. SPRING	001
146	A 000 071 01 17	. SPRING RETAINER	001
150	A 000 070 02 51	. COVER	001
154	A 000 070 00 81	. LINE	001
158	A 000 071 35 71	. SCREW	003
168	A 000 070 05 87	. NOZZLE Replaced by: A 000 070 08 87  [051] EXHAUST STOCK OF OLD PARTS UP TO ENGINE	-
168	A 000 070 08 87	. NOZZLE (NOZZLE SLEEVE)	001
170	A 000 071 66 16	. SPRING	001
176	A 000 071 09 70	. STUD FULL INTAKE ADJUSTING SCREW	001
184	A 011 997 39 45	. . SEAL RING  [062] Up to engine:	001
186	A 000 988 51 35	. CAP PROTECTION AGAINST MISHANDLING	001
187	A 000 070 01 42	. VALVE (FLOAT NEEDLE VALVE)	001
190	A 000 071 19 60	. . SEAL RING	001
193	A 000 070 00 43	. FLOAT	001
196	A 000 071 93 71	. SCREW	004
199	A 000 071 94 71	. SCREW	002
----	A 001 071 34 71	. SCREW  [062] Up to engine:	001
202	A 000 071 46 80	. GASKET	001
205	A 000 070 04 18	. PISTON Replaced by: A 000 070 06 18  [051] EXHAUST STOCK OF OLD PARTS UP TO ENGINE	-
205	A 000 070 06 18	. PISTON  [062] Up to engine:	001
208	A 000 071 00 26	. . DIAPHRAGM Replaced by: A 000 071 08 26  [415] THIS NOTE OF REPLACEMENT APPLIES ONLY TO THE ITEM LIST...	-
208	A 000 071 08 26	. . DIAPHRAGM	001
209	A 000 071 15 76	. . WASHER	001
211	A 000 071 98 71	. . SCREW	004
214	A 000 071 47 16	. SPRING Replaced by: A 000 071 82 16	-
214	A 000 071 82 16	. SPRING	001
217	A 000 071 01 87	. STOP PLATE  [062] Up to engine:	001
220	A 000 070 04 87	. NOZZLE (NOZZLE NEEDLE)	001
225	A 000 071 97 71	. SCREW	001
----	A 000 997 72 35	. PLUG  [402] NO LONGER AVAILABLE	-
228	A 000 071 88 71	. SCREW Replaced by: A 001 071 48 71	-
228	A 001 071 48 71	. SCREW	003
----	A 000 070 12 67	. DASHPOT Replaced by: A 000 070 13 67	-
232	A 000 070 13 67	. DASHPOT Replaced by: A 000 070 14 67 +001 A 000 997 84 86  [052] Up to engine:	-
232	A 000 070 14 67	. DASHPOT Replaced by: A 000 070 23 67	-
232	A 000 070 23 67	. DASHPOT  [053, 062] As of engine	001
239	A 000 997 56 35	. PLUG Replaced by: A 000 997 84 86 +001 A 000 070 14 67  [052] Up to engine:	-
239	A 000 997 84 86	. PLUG YELLOW  [053, 062] As of engine	001
240	A 000 987 11 45	. LOCKING CAP  [062] Up to engine:	NB
----	A 000 586 97 07	. REPAIR KIT Replaced by: A 001 586 11 07	-

243	A 001 586 11 07	REPAIR KIT (GASKET KIT),CARBURETOR [062] Up to engine: SEE FIG. NO.: 022	001	
259	A 115 071 04 80	GASKET Replaced by: A 115 071 05 80	-	
259	A 115 071 05 80	GASKET [005] As of engine	002	
263	A 115 071 00 55	COVERING	001	
267	A 115 071 03 81	INSULATING FLANGE Replaced by: A 115 071 04 81	-	
267	A 115 071 04 81	INSULATING FLANGE [005] As of engine	001	
-----	A 115 071 03 68	FLANGE Replaced by: A 115 071 05 68	-	
270	A 115 071 05 68	FLANGE Replaced by: A 102 071 01 68	-	
270	A 102 071 01 68	FLANGE Replaced by: A 102 071 13 68	-	
270	A 102 071 13 68	FLANGE	001	
273	N 912004 006102	LOCK WASHER	004	
277	N 000912 006025	SCREW Replaced by: N 000912 006175	-	
277	N 000912 006175	SCREW Replaced by: A 001 990 72 12	-	
277	A 001 990 72 12	SCREW	004	
281	A 115 071 01 80	GASKET	001	
284	A 115 071 00 71	SCREW	004	
288	N 072551 001680	ELECTRIC CABLE [404] ORDER BY THE METER	001	
289	N 900261 006000	CABLE SHOE	001	
289	N 900261 008001	CABLE SHOE	001	
294	A 115 070 01 24	BEARING BRACKET	001	LM
297	A 115 070 12 24	BEARING BRACKET	001	RM
303	A 115 070 13 24	BEARING BRACKET	001	A
310	A 115 990 30 40	WASHER	002	
315	A 115 070 03 22	LEVER	001	M
319	A 115 070 19 21	LEVER	001	A
324	A 115 070 00 21	LEVER	001	M
329	A 115 070 20 21	LEVER	001	A
-----	A 115 070 21 21	LEVER Replaced by: A 115 070 24 21 [401, 021] EXHAUST STOCK OF OLD PARTS	-	RA
334	A 115 070 24 21	LEVER	001	A
339	A 115 070 19 24	BEARING BRACKET [036, 402] Up to engine:	001	R
339	A 115 070 20 24	BEARING BRACKET [037, 402] As of engine	001	R
342	A 115 072 03 40	BRACKET [036, 402] Up to engine:	001	R
344	N 000933 006106	SCREW Replaced by: N 304017 006016	-	R
344	N 304017 006016	SCREW	002	R
349	N 000137 006204	SPRING WASHER	002	R
351	A 115 072 04 40	BRACKET BOWDEN CABLE [046] As of engine 954 22/62 061994	001	RM
353	A 115 070 13 22	LEVER [402] NO LONGER AVAILABLE	001	R
355	N 000931 006094	SCREW [036] Up to engine:	001	R
357	N 000933 006102	SCREW [037] As of engine	001	R
358	A 180 072 03 93	ROLLER	001	M
363	N 006799 004001	LOCK PLATE	001	M
-----	A 115 072 00 50	BUSHING Replaced by: A 115 072 04 50	-	
369	A 115 072 04 50	BUSHING	004	M
369	A 115 072 04 50	BUSHING	002	A
374	N 006799 007007	LOCK PLATE	002	M
374	N 006799 007007	LOCK PLATE	001	A
379	A 000 070 09 75	ROD FROM CONTROL LEVER TO THROTTLE VALVE LEVER	001	LM

----	A 000 070 08 75	ROD Replaced by: A 616 070 06 75 [415, 040] THIS NOTE OF REPLACEMENT APPLIES ONLY TO THE ITEM...	-	RM
380	A 616 070 06 75	ROD	001	RM
381	N 000934 005008	. NUT [041] As of engine	002	RM
382	A 000 991 16 22	. BALL SOCKET Replaced by: A 000 991 89 22	-	RM
382	A 000 991 89 22	. BALL SOCKET [041] As of engine	002	RM
----	A 000 070 07 75	ROD Replaced by: A 000 070 45 75 [401, 017] EXHAUST STOCK OF OLD PARTS	-	A
384	A 000 070 45 75	ROD	001	A
----	A 000 070 36 75	ROD Replaced by: A 115 070 66 75 [401, 013] EXHAUST STOCK OF OLD PARTS	-	R
385	A 115 070 66 75	ROD [015] As of engine	001	R
----	N 000934 005008	NUT [015] As of engine	002	R
394	A 000 991 89 22	BALL SOCKET [015] As of engine	002	R
404	N 007603 012405	SEAL RING	001	
409	N 000961 012056	SCREW	001	
413	A 115 078 08 41	BRACKET	001	
423	A 115 078 07 41	BRACKET Replaced by: A 115 078 08 41 +001 A 616 223 01 41 +001 N 000961 012056 [401, 020] EXHAUST STOCK OF OLD PARTS	-	
432	A 115 995 00 15	CLAMP	001	L
436	N 912004 006102	LOCK WASHER	001	
441	N 000084 006133	SCREW	001	L
446	A 115 078 07 81	HOSE	002	
----	A 114 476 20 26	HOSE Replaced by: A 115 141 12 83	-	
----	A 114 997 18 82	HOSE Replaced by: A 115 141 12 83 [401, 010, 415] EXHAUST STOCK OF OLD PARTS	-	
----	A 107 997 14 82	HOSE Replaced by: A 115 141 12 83 [401, 010, 415] EXHAUST STOCK OF OLD PARTS	-	
----	A 115 141 08 83	HOSE Replaced by: A 115 141 12 83 [401, 018] EXHAUST STOCK OF OLD PARTS	-	
----	A 115 141 09 83	HOSE Replaced by: A 115 141 12 83 [401, 036, 038] EXHAUST STOCK OF OLD PARTS	-	
470	A 115 141 12 83	HOSE FROM CARBURETOR TO INTAKE MANIFOLD	001	
472	N 916002 010100	CLAMP	002	
472	N 916033 012100	CLAMP	003	
475	A 115 078 00 85	PIPE BRACKET	002	
----	A 115 078 01 85	PIPE BRACKET Replaced by: A 115 078 00 85	-	
485	A 001 997 69 90	LOOM TIE CARBURETOR HEATING	004	
490	A 115 070 68 75	ROD VEHICLES EQUIPPED WITH COOLING WATER PREHEATER AND BOUND FOR SCANDINAVIA	001	A
490	A 115 070 41 75	ROD Replaced by: A 115 070 70 75 [045] EXHAUST STOCK OF OLD PARTS UP TO ENGINE	-	A
490	A 115 070 70 75	ROD Replaced by: A 130 070 22 75	-	LA
490	A 130 070 22 75	ROD CONTROL PRESSURE	001	LA
490	A 115 070 71 75	ROD CONTROL PRESSURE	001	RA
496	A 110 277 05 50	. BUSHING	001	A
498	N 073379 006101	. HOSE [404] ORDER BY THE METER	001	A

500	A 115 300 00 86	. END PIECE Replaced by: A 000 991 88 22	-	A
500	A 000 991 88 22	. BALL SOCKET	001	A
505	N 000934 005008	. NUT	001	A
509	N 000125 006421	WASHER ROD TO CONTROL PRESSURE LEVER	001	A
511	N 000094 002053	COTTER PIN ROD TO CONTROL PRESSURE LEVER	001	A